

TO PREPARE LABEL:

REMOVE MOUNTING SCREWS
AND PLASTIC WINDOW.

REMOVE A SINGLE SHEET OF
WHITE CARBON AND A SIN-
GLE SHEET OF BLACK PAPER.

TYPE OR PRINT DIRECTLY ON
THE WHITE CARBON PAPER
WITH THE BLACK PAPER
UNDERNEATH SO THAT THE
DESIRED INFORMATION IS
IMPRESSED ON THE BLACK
PAPER.

DISCARD USED CARBON PAPER
AND PLACE LABEL DIRECTLY
BENEATH PLASTIC WINDOW.

REPLACE MOUNTING SCREWS.