

NanoVNA  
Setting Trace 0 to show CH0 Reflect

All instructions assume that you have turned the NanoVNA on with the slide switch at the top.

1. Press the button on the top of the NanoVNA to see the **Main Menu** showing **Trace, Format, Scale ....**
2. If another menu appears, tap **Back**, at the bottom of the menu and continue tapping Back until you see the **Main Menu**
3. Select **Display**
4. Select **Trace**
5. Tap **Trace 0** repeatedly until the check mark shows at the left of the **Trace 0** label
6. Tap **Back** until you see the **Main Menu**
7. Tap **Display**
8. Tap **Channel**
9. **Tap CH0 Reflect until the check mark shows at the left of the CH0 label**
10. Now **Trace 0** will show what is happening at **CH0**, also called S11 (this is a yellow line)
11. Turn this trace on or off by returning to the **Trace** menu and tapping **Trace 0** until the check mark appears (on) or disappears (off)