


RB-47E

# Gunner's STATION

## COPILOT'S STATION AFT



- |   |  |
|---|--|
| <ol style="list-style-type: none"> <li>1. OXYGEN WARNING LIGHT</li> <li>2. ASSIST HANDLE</li> <li>3. UPPER AIR OUTLET</li> <li>4. RADIO COMPASS LOOP ANTENNA ①</li> <li>5. GUN-LAYING RADAR SCOPE</li> <li>6. GUNNER'S ASH TRAY</li> <li>7. PANEL LIGHTS CONTROL</li> <li>8. TURRET CONTROL PANEL</li> <li>9. CANOPY AIR BOTTLE PRESSURE GAGE</li> <li>10. COPILOT'S DATA CASE</li> </ol> | <ol style="list-style-type: none"> <li>11. LANDING GEAR EMERGENCY EXTENSION LEVERS</li> <li>12. LANDING GEAR INDICATOR LIGHTS</li> <li>13. RELIEF CONTAINERS</li> <li>14. A-5 INDICATOR CONTROL PANEL</li> <li>15. ARC-21 ANTENNA COUPLER</li> <li>16. GUNNER'S FOOT MICROPHONE SWITCH</li> <li>17. LOWER AIR OUTLET</li> <li>18. MANUAL ANTENNA CONTROL HANDLE</li> </ol> |
|---|--|

① AF 51-5258 thru 52-789 [www.mightmanuals.org](http://www.mightmanuals.org)

Figure 4-63.