

INSTRUCTIONS FOR FEEDING PAPER

P-149889

1. TAKE CORE OF USED PAPER ROLL FROM BRACKET ON DOOR AND REMOVE SPINDLE FROM IT BY PRESSING SPRING AT RIGHT END.
2. HOLD NEW PAPER ROLL WITH LOOSE END ON TOP AND TOWARD TABLE. NOW INSERT SPINDLE INTO LEFT END OF ROLL AND PLACE IT IN SLOTS OF BRACKET.
3. INSERT END OF PAPER BETWEEN SLACK BAR AND WIRE BAIL, AND PULL PAPER BACK OVER BRACKET. FOLD CORNERS OF PAPER AT APPROXIMATELY 45 DEGREES TO OBTAIN A POINT.
4. INSERT PAPER UNDER SPRING CLIP ON BRACKET, PUSHING CLIP FROM UNDERNEATH AND LINE UP PAPER WITH WHITE LINES.
5. CLOSE THE DOOR. PAPER CAN NOW BE PICKED UP BACK OF TELETYPEWRITER BY PULLING PAPER TO RIGHT TO DISENGAGE IT FROM SPRING CLIP.
6. INSERT PAPER THROUGH SLOT IN TELETYPEWRITER COVER, THEN THROUGH PAPER GUIDE, AND THENCE AROUND PLATEN OF CARRAGE AND UNDER RETAINING WIRE JUST ABOVE PLATEN.
7. OPERATE PAPER RELEASE LEVER; ADJUST PAPER TO PROPER ALIGNMENT AND RESTORE LEVER.

SPRING
CLIP

SLACK BAR
& BAIL

PAPER ROLL

SPINDLE

BRACKET

PRINTED IN U.S.A.

